

YOU MUST
SUBSCRIBE TO YOUR
NETWORK PROVIDER'S
SERVICES BEFORE THESE FEATURES WILL
WORK. A QUARTERLY FEE IS PAYABLE



This equipment is not designed for making emergency telephone calls when the power fails.
Alternative arrangements should be made for access to emergency services.

This product is intended for connection to analogue public switched telephone networks
and private switchboards in the United Kingdom.

Synergy 3100

Digital Cordless Telephone with Caller Display*
and Call Waiting* featuring DECT

**User
Guide**

**Please open this page for an 'at a glance'
guide to your Synergy 3100**

At a glance

Volume buttons

Use to adjust the handset earpiece speech volume and handset and base ringer volume.

Also used to access the redial and calls list and scroll through the directory, menu options, redial and calls list.

Secrecy button

During a call press to mute the call so your caller cannot hear you talk to someone close by.

Also used as a delete, edit and exit button.

Talk button

Use to make, receive and end calls.

Keypad

Recall/Power button

For use with a switchboard/PBX and BT Select Services. Also used to switch off the handset.

Handset

Red light

To indicate that the phone is ringing or in use.

Liquid Crystal Display

Display shows you incoming caller's details, the name and/or number you have dialled, and the status of the handset.

Handsfree button

Use to answer calls or make a call using the handsfree mode.

Menu button


Use to access and select the options in the menu.

Phonebook button

Use to access the 50 names and numbers stored in the phonebook.

Internal button

To make internal calls between handsets registered to the base.



Base

Power/In use light


Green light remains lit when there is power to the phone and flashes when the line is in use.

Page button

Allows you to page the handset(s) to alert a handset user or to locate a handset.

Charging light

Lights up red to indicate charging when the handset is on the base.



Explanation of the display icons

Standby screen

To personalise the name of your handset, see page 21.













































HS1

Displays the number of the handset at all times.


Icon	Steady	Flashing
	External line in use	Incoming call
	Internal call	Internal call from another handset
	In calls list	New call received in calls list
	3 way conversation in progress	
		Battery exhausted
	Battery weak	
	Battery half-full	
	Battery full	
	Phonebook	
	Menu in use	
	Handset linked to base station	Out of range or searching for base station
	In handsfree mode	

Quick Guide


Information for the handset settings

Function	Key combination
Answer a call/End a call	
Make a call	 
Redial a number	 
Store a number in the memory	   enter the name  enter the telephone number 
Dial a number in the memory	   
Adjust the earpiece volume	During a call, press the   during a call until the required level is reached.
Secrecy on/off	During a call, press  to switch on and to again switch off.
Transfer call to another handset	 enter handset number 
Three way conversation	 enter handset number  
Access to redial list	  – keep pressing to scroll.
Access to calls list	  – keep pressing to scroll.
Set handset ringer volume	   HANDSET   RING VOL    to select volume 
Set base unit ringer volume	  SETUP  BASE VOL    to select volume 


Important

*If the handset is sitting in the base when a call comes in, you can pick it up and answer it automatically without pressing the  button.

Menu Structure



Cont.....



Important. If you make a mistake you can return to the previous menu heading by pressing the **X** button. If you press and hold the **X** button at any time you will return to the standby screen. After 30 seconds if no buttons are pressed the handset will automatically return to the standby screen.

In this guide

Note

There is a detailed INDEX at the end of this guide, see page 38.

At a glance

Handset	1
Display icons	2
Quick Guide	3
Menu structure	4

Introduction

Unpacking your Synergy 3100	8
For your records	8
Safety information	9

Setting up

Plan the location	10
-------------------	----

Using the telephone

Making and receiving calls	13
Call timer	13
Handsfree	14
Redial	15
Secrecy	15
Name and number	
Phonebook	16
Paging handsets	18

Handset settings

19

Base settings

22

Caller Display and Call Waiting

Caller Display	25
Calls list	25
Call Waiting	27

Using additional handsets and bases

Internal calls	31
Transferring calls	31

Help

33

General information

Guarantee	35
Technical information	36
Switchboard compatibility	36
Switchboard external line access code	36
Recall	36

Index

38

Note

In this user guide, we've included helpful tips and useful notes. They are shown in a white box like this.

Introduction

Your Synergy 3100 has been designed for ease of use and made to the high standards set by BT

Please read the instructions carefully before use and keep this user guide for future reference.

DECT


By purchasing the Synergy 3100 you now own a product which combines the advantages of cordless operation with the performance of a high quality corded telephone. It complies with the Digitally Enhanced Cordless Telecommunications (DECT) standard and offers unparalleled quality and features.

You can use up to 5 handsets with your Synergy 3100 base station without the need for additional wiring.

This user guide applies to both single and multiple handset systems. The internal call functions described in this guide apply only to Synergy 3100 base stations with more than one handset connected.

Important

If you wear a hearing aid, please note that the Synergy 3100 works by sending radio signals between the base station and the handset. These signals may interfere with some hearing aids, causing a humming noise.



Unpacking your Synergy 3100

If anything is missing, please contact your place of purchase immediately.

One Synergy 3100
base station




One Synergy 3100
handset




2 x AAA rechargeable
batteries



One power supply
for base station
(Item code: 872260)



One telephone line cord



In addition:

If you have purchased the
Synergy 3100 Twin:

One Synergy 3000
handset



One Synergy 3000
charger



2 x AAA rechargeable
batteries



One power supply
for charger
(Item code: 003313)



For your records

Date of purchase:

Place of purchase:

Serial number:

For guarantee purposes proof of purchase is required so please keep your receipt.

If you change your PIN, keep a record of the new number here:
(original setting 0000)

--	--	--	--

See *page 23* for more information.

Safety information

General

Only use the power supply included with the product. Using an unauthorised power supply will invalidate your guarantee and may damage the telephone. The item number for the mains power supply is 872260.

Only use the approved rechargeable batteries supplied. Spare rechargeable batteries are available from the Synergy Helpline **08706 058 047**.

Do not open the handset or base station. This could expose you to high voltages or other risks. Contact the Helpline for all repairs.

Radio signals transmitted between the handset and base may cause interference to hearing aids.

It is recommended that advice from a qualified expert be sought before using this product in the vicinity of emergency/intensive care medical equipment.

It is recommended that if you have a pacemaker fitted you check with a medical expert before using this product.

Your product may interfere with other electrical equipment, e.g. TV and radio sets, clock/alarms and computers if placed too close. It is recommended that you place your product at least one metre away from such appliances to minimise any risk of interference.

Never dispose of the batteries in a fire. There is a serious risk of explosion and/or the release of highly toxic chemicals.

Cleaning

Simply clean the handset and base station with a damp (not wet) cloth, or an anti-static wipe. Never use household polish as this will damage the product. Never use a dry cloth as this may cause a static shock.

Environmental

Do not expose to direct sunlight.

The product may heat up when the batteries are being recharged. This is normal. However, we recommend that you do not place the product on antique/veneered wood to avoid damage.

Do not stand your product on carpets or other surfaces which generate fibres, or place it in locations preventing the free flow of air over its surfaces.

Do not submerge any part of your product in water and do not use it in damp conditions, such as bathrooms.

Do not expose your product to fire, explosive or other hazardous conditions.

There is a slight chance that your phone could be damaged by an electrical storm. We recommend that you unplug the power and telephone line cord for the duration of the storm.

Setting up

Follow these steps to set up your Synergy 3100 ready for use

Plan the location

Position your Synergy 3100 within 2 metres of a power socket and phone socket otherwise extension cables will be required.

Make sure it is at least 1 metre away from other electrical products to avoid interference.


Do not place your Synergy 3100 product in the bathroom or other humid areas.

Note

The Synergy 3100 has a range of up to 300 metres outdoors and up to 50 metres indoors. The range will be reduced when there is no clear line of sight between the base and handset. Thick stone walls can severely affect the range.

1 Connect the power supply to the base


Plug the power adaptor into the mains power socket and switch on. The green Power/In Use light comes on.



Note

The base station must be plugged into the mains power socket at all times.


2 Install the rechargeable batteries in the handset



The handset uses two rechargeable Nickel Metal Hydride (Ni-MH) AAA batteries which are supplied. Take care to insert the batteries as shown and then fit the battery cover (the battery cover may be found in the packaging with the batteries).

3 Charge the handset batteries for at least 16 hours

Before you use your Synergy 3100 for the first time, it is important to have the handset batteries fully charged. The batteries need to charge continuously **for at least 16 hours to reach full charge.**

Place the handset on the base. The red charging light will come on. The handset comes pre-registered to the base station as SYNERGY HS1. This is shown on the display. The  icon and the battery icon are shown on the display. Once the handset is fully charged, the display shows a full battery symbol.

BATTERY LEVELS



WEAK


HALF-FULL

FULL

Battery low warning

If the handset battery symbol is empty and flashing, and you hear a warning beep every 10 seconds, you will need to recharge your handset before you can use it.

Note

The  symbol on your handset display indicates when you are in range of the base station. If the symbol flashes and you hear a warning beep, you are out of range and will need to move closer to the base station.

Battery performance

Under no circumstances should non-rechargeable batteries be used. Only use the approved batteries, type: rechargeable Nickel Metal Hydride (Ni-MH); size AAA; capacity 550mAh 1.2v. Using unapproved batteries will invalidate your guarantee and may damage the telephone.


To keep your batteries in the best condition, leave the handset off the base station for a few hours at a time. (after the initial 16 hour charge).

Please note, however, that new Nickel Metal Hydride (Ni-MH) batteries do not reach their full capacity until they have been in normal use for several days.

*Fully discharging the batteries at least once a week will help them last as long as possible. However, the charge capacity of rechargeable batteries will reduce with time as they wear out, so reducing the talk/standby time of the handset. Eventually they will need to be replaced. New batteries can be obtained from the BT Synergy Helpline **08706 058 047**.*

Note: *Under ideal conditions, the handset batteries should give about 14 hours talktime or 350 hours standby on a single charge. Optimum times for talk and standby are only achieved when the handset batteries are fully charged.*


- 4** Connect the telephone line cord to the Synergy 3100 base station



- 5** Connect the telephone line cord

Note

It is recommended that you do not connect the telephone line cord to the phone socket until your handset is fully charged. This will prevent the risk of the batteries discharging during a conversation, which could cause you to lose a call.





Customer Helpline

*If you have any difficulties setting up your Synergy 3100 please call the Helpline on **08706 058 047**.*

Your Synergy 3100 is now ready for use.

Using the telephone

Note

To exit and return to the previous menu at any time, press the  button. If you press and hold the  button you will return to the standby screen.

To switch the handset on and off



Press *and hold* the **POWER** button to switch the handset off.




To switch the handset on, press *and hold* the **POWER** button again.

Making and receiving calls

To make an external call



Press the **TALK** button. You will hear the dial tone and the display will show the  symbol.



Enter the number you want. The number is dialled automatically.

Preparatory dialling

Preparatory dialling allows you to enter the number before pressing the **TALK** button. This enables you to correct any mistakes before you actually make the call.



Enter the number to be dialled.

The number is shown in the display.



(If you make a mistake, press the **X** button to delete the incorrect digit).




When you have entered the number correctly, press the **TALK** button to dial the number.

Call timer

Your handset will automatically time the duration of all external calls.

The handset display shows the call duration both during your call and for a few seconds after it is complete.



To end a call

Press the **TALK** button.

Or

Place the handset back on the base.

To receive a call

When the phone rings the display will show **CALL** and the **EXT** symbol will flash.

If you have subscribed to a Caller Display Service, the number (and name if stored in the phonebook) will be displayed.



Press the **TALK** button.

Or

If the handset is on the base, simply lift it up and speak.

In standby mode:

Press the button.

Press the **DOWN** button until **HANDSET** is displayed.

Press the button.

Press the **DOWN** button until **EAR VOL** is displayed.

Press the button.

Press the **UP** or **DOWN** button until you reach the required level.

Press the button to confirm the selected level.

Press *and hold* the button to return to the standby screen.

**Handsfree**

Handsfree allows you to talk to your caller without holding the handset and enables other people in the room to listen to your conversation.

To adjust the speech volume during a call*During a call:*

You can adjust the earpiece volume. There are 5 levels to choose from.



Press the **UP** or **DOWN** button until you reach the required level. This will be shown on the display.
eg: **EAR VOL 3**.

To make a handsfree call

Dial the number.

Press the **HANDSFREE** button.

The display will show the icon to indicate handsfree is active. You will hear the number being dialled out.

To switch back to using the handset at any time, press the **TALK** button.



To adjust the handsfree volume

Whilst in handsfree mode you can increase or decrease the handsfree volume.



Press the **UP** or **DOWN** button to adjust the volume.

The volume will be adjusted accordingly.

To answer a call in handsfree

When the phone rings:



Press the **HANDSFREE** button. The call is transferred to the loudspeaker.

To switch to handsfree during a call

During a call you can switch to handsfree mode.



Press the **HANDSFREE** button. The call is transferred to the loudspeaker.



Press the **TALK** button to switch back to using the handset.

Redial

You can redial up to 5 of the last numbers called. They are stored in the redial list. If you have stored a name to go with a number in the phonebook, the name will be displayed instead. See *"Name and number Phonebook"*, page 16.

Redial



Press the **UP** button to enter the redial list.



Continue pressing the **UP** button to view the next number in order of most recent first.



Press the **TALK** button when the number (or name) you want to call is displayed. The number is dialled automatically.

Secrecy

When on a call you can talk to someone in the same room, without your caller hearing.

To switch secrecy on / off



During a call, press the **X** button. The display will show **MUTE**. Your caller cannot hear you.



Press the **X** button again to resume your call.

Name and number Phonebook


You can store up to 50 of your most frequently used names and numbers in the Phonebook. Stored numbers can be no longer than 20 digits.

To store a name and number in the Phonebook




Press the  button to enter the menu.



The display will show PHONEBK, press the  button.



The display will show ADD, press the  button.

The display shows NAME ?



Enter the name using the letters on the keypad. Names can be no longer than 8 characters.

Entering names:



Use the keypad letters to enter names, e.g. if you wish to store the name TOM:



To enter the letter T, press the **8** button once.



To enter O, press the **6** button *three times* and wait for the cursor to move across.



To enter M, press the **6** button once.



If you enter a digit incorrectly, press the **X** button to delete it.



Press  to confirm the name. You will hear a confirmation beep.

The display shows NUMBER ?




Enter the telephone number you want to store.



Press the  button. You will hear a confirmation beep.



Alternatively, press the  button to continue storing entries in the phonebook.



Press *and hold* the **X** button to return to the standby screen.

Note

*Press the **1** button once to insert a space, press twice for a - (hyphen), press 3 times for the number 1.*

Note

If you subscribe to a Caller Display Service (see page 25) and want directory names to be displayed when a call is received from one of your directory numbers, you must ensure that you always enter the full telephone number, including the national code.

To enter a pause in a stored number

You may want to enter a pause when storing international numbers, charge card numbers or if you connect your telephone to a switchboard. (For more information on switchboard use *see page 36.*)

When storing the number, press *and hold* the **UP** button, until a P is displayed, at the point where you want to enter the pause.

You may enter as many pauses as required.

To dial a name and number from the Phonebook

Press the **PHONEBOOK** button to enter the phonebook.

Use the **UP** or **DOWN** button to scroll through.

Or

Enter the first letter of the name you want, e.g. for Tom, press the **8** button to search for names beginning with T.


Press the **TALK** button to dial the number of the name displayed. The number is dialled automatically.


Note

You can scroll in either direction to search through the list.

To edit an entry in the Phonebook


Press the  button to enter the menu.


The display will show PHONEBK, press the  button.


Use the **DOWN** button to scroll to MODIFY and press the  button.


Use the **UP** or **DOWN** button to find the name you want to edit.


Press the  button.

Use the  button to delete unwanted letters. You can enter new letters as shown in 'Entering names' on page 16.

Press  to store the new name. You will hear a confirmation beep.

The number will be displayed. Use the  button to delete unwanted digits and re-enter the correct ones.

Press the  button to store the new number. You will hear a confirmation beep.

Press *and hold* the  button to return to the standby screen.




To delete a Phonebook entry



Press the  button to enter the menu.



The display will show PHONEBK, press the  button.




Use the **DOWN** button to scroll to DELETE and press the  button.




Use the **UP** and **DOWN** buttons to scroll through to the entry you want to delete.




When you have found the name to delete, press the  button.




The number will be displayed, press the  button.



The display will show CONFIRM?, press the  button.

You will hear a confirmation beep. The number is now deleted.



Press *and hold* the  button to return to the standby screen.

Paging handsets

You can page your handset(s) from the base station to alert a handset user that they are wanted or to locate a missing handset.


Note

Paging calls cannot be answered by a handset.

To page a handset from the base



Press the **PAGE** button on the base.

The handset(s) will ring.
The display will show INT  flashing.



To stop paging, press the **PAGE** button again.

Or



To stop paging, press any button on the handset.


Handset settings

To switch keypad beeps on and off




Press the  button to enter the menu.




Use the **DOWN** button to scroll to **HANDSET** and press the .



The display will show **BEEP**, press the .



The display will show **KEYTONE**, press the .




Use the **UP** or **DOWN** button to select either **ON** or **OFF**.




Press the  button. You will hear a confirmation beep.



Press *and hold* the  button to return to the standby screen.

Important

Press and hold the  button at any time to exit the menu and return to the standby screen.


To adjust the handset ringer volume

There are 5 levels to choose from (**1-5**), or you can turn the ringer off altogether.




Press the  button to enter the menu.



Use the **DOWN** button to scroll to **HANDSET** and press the .



Use the **DOWN** button to scroll to **RING VOL** and press the .




You will hear the current volume setting and it will be shown on the display.




Use the **UP** or **DOWN** button to select the required volume (**VOLUME 1-5** or **VOL OFF**). You will hear a sample ring.



Press the  button to confirm the new setting. You will hear a confirmation tone.




Press *and hold* the  button to return to the standby screen.

To set the external or internal ringer melody

There are 5 melodies to choose from and you have the option to choose a different melody for external and internal calls. (Internal calls for when you have more than one handset).

Press the  button to enter the menu.


Use the **DOWN** button to scroll to **HANDSET** and press the .


Use the **DOWN** button to scroll to either **INT MEL** or **EXT MEL**.

Press the .

You will hear the current melody setting and it will be shown on the display. e.g. **MELODY 4**.

Use the **UP** or **DOWN** button to select the required melody. You will hear a sample melody.


Press the  button to confirm the new melody. You will hear a confirmation tone.

Press *and hold* the  button to return to the standby screen.

To switch auto-talk on/off

When the handset is on the base or the charging unit you can answer the call by picking it up from the base. This will automatically answer the call without having to press the **TALK** button.


Press the .


Use the **DOWN** button to scroll to **HANDSET** and press the .

Use the **DOWN** button to scroll to **AUTO ANS**.

Press the .

Use the **UP** or **DOWN** button to turn **AUTO-TALK ON** or **OFF**.

Press the  button to confirm.

Press *and hold* the  button to return to the standby screen.


To name a handset

The handset name is pre-set as SYNERGY, however, you can personalise each handset by giving it a name.




Press the  button to enter the menu.



Use the **DOWN** button to scroll to **HANDSET** and press the .





Use the **DOWN** button to scroll to **NAME** and press the .




Press the  button to delete the name already set.



Enter the name you want using the keypad and press the  button, correct any mistakes by pressing the .

You will hear a confirmation beep.



Press *and hold* the  button to return to the standby screen.


To set the handset language

If you wish, you can change the language used on the handset display. You can choose from English, Francais, Deutch, Nederl, Italiano, Espanol, Portuges, Norsk, Dansk, Svenska and Suomi.




Press the  button to enter the menu.



Use the **DOWN** button to scroll to **HANDSET** and press the .




Use the **DOWN** button to scroll to **LANGUAGE** and press the .




Use the **UP** or **DOWN** button to scroll through the language options.



Press the  button to confirm your choice. You will hear a confirmation beep.



Press *and hold* the  button to return to the standby screen.

Note

To default back to the English language follow:



Press the **MENU** button.



Press the **DOWN** button *three times*.



Press the **MENU** button.



Press the **UP** or **DOWN** button until **ENGLISH** is displayed.




Press the **MENU** button *twice*.


Base settings

To adjust the base ringer volume


There are 5 levels to choose from (1-5), or you can turn the ringer off altogether.


Press the  button to enter the menu.

Use the **DOWN** button to scroll to **SETUP** and press the  button.

The display will show **BASE VOL**. Press the  button.

Use the **UP** or **DOWN** button to select the required volume (**VOLUME 1-5** or **VOL OFF**). You will hear a sample ring.


Press the  button to confirm the new setting. You will hear a confirmation beep.


Press *and hold* the  button to return to the standby screen.

To adjust the base ringer melody


There are 5 melodies to choose from (1-5)


Press the  button to enter the menu.

Use the **DOWN** button to scroll to **SETUP** and press the  button.

Use the **DOWN** button to scroll to **BASE MEL** and press the  button.

Use the **UP** or **DOWN** button to select the required melody (**MELODY 1-5**). You will hear a sample melody.

Press the  button to confirm the new setting. You will hear a confirmation beep.


Press *and hold* the  button to return to the standby screen.


To select a base station

If a handset is registered to more than one base station, you can select which base your handset will use.


For more information on registering your handset to another base, *see page 29*.


Press the  button to enter the menu.

Use the **DOWN** button to scroll to **SETUP** and press the  button.

Use the **DOWN** button to scroll to **SEL BASE** and press the  button.

Use the **UP** or **DOWN** button to select the base you want (BASE 1-4).

Press the  button. You will hear a confirmation beep.


Press *and hold* the  button to return to the standby screen.




To change the base station PIN code

If you change the base station PIN, keep a record of the new number by writing it in the space provided on *page 8*. You will need to use your base station PIN for registering handsets and for some other optional settings.

Press the  button to enter the menu.

Use the **DOWN** button to scroll to **SETUP** and press the  button.

Use the **DOWN** button to scroll to **PIN CODE** and press the  button.

The display will show **PIN?**

Enter your 4-digit PIN (original setting 0000).

Press the  button.


The display will show **NEW PIN**.


Enter your new 4-digit PIN.

Press the  button.

The display will show **RETYPE**.

Re-enter your new 4-digit PIN.

Press the  button. You will hear a confirmation beep.

Press *and hold* the  button to return to the standby screen.




To default/reset the handset and base to their original/default factory settings

Please note that if you reset your Synergy 3100 the Phonebook, Redial and Calls list will be deleted.




Press the  button to enter the menu.



Use the **DOWN** button to scroll to **SETUP** and press the  button.



Use the **DOWN** button to scroll to **DEFAULT** and press the  button.



The display will show **PIN?**



Enter the base PIN (original setting 0000)



Press the  button.

You will hear a confirmation tone at the base and handset. The handset display will flash **BASE 1** and then **SYNERGY HS1**.

Your Synergy 3100 is now reset to the factory settings.

The default settings are:

Earpiece volume	3
Handset & Base ringer volume	3
Handset & Base melody	1
PIN code	0000
Handset name	SYNERGY
Handset language	ENGLISH
Button beeps	ON
Battery low indicator beeps	ON
Out of range warning beeps	ON
Auto answer	ON
Dialling mode	DTMF
Pause after picking up line / dial-out code	3 seconds
Phonebook	Empty
Redial list	Empty
Calls list	Empty

Caller Display and Call Waiting

Important

To use Caller Display or Call Waiting you must first subscribe to your network provider's Caller Display or Call Waiting Service. A quarterly fee is payable.

For more information on BT's Select Services, call BT free on 0800 800 150.

Using Caller Display

If you subscribe to a Caller Display Service you can see your caller's number (provided it is not withheld) on your handset display, as well as the time and date of their call. If you have your caller's name and number stored in your handset phonebook, you will see the name of your caller displayed instead of the number.

Please ensure that you have stored the full telephone number, including the area code, otherwise the name will not match the number stored in the phonebook.

Whether you take a call or not, the caller's details are stored in the Calls list. You can display, scroll through and dial numbers on the list and copy them into the phonebook.

Caller information not available

With some incoming calls the telephone number of the caller is not available and cannot therefore be displayed.

In this case, your Synergy 3100 provides you with some explanatory information about the type of call received. This will be one of the following.

UNAVAILA

The number is unavailable.

WITHHELD

The caller has withheld their number.

RINGBACK

Ringback call.

OPERATOR

The call has been made via the operator.

PAYPHONE


The caller is ringing from a payphone.

INTERNAT

International call.

Calls list

The Calls list contains the telephone numbers of your last 20 callers.

New calls in the Calls list are indicated by the flashing  symbol on the display.

If a call is received when the Calls list is full then the oldest entry will be deleted automatically.


To enter and view the Calls list




Press the **DOWN** button to enter the Calls list. The  symbol is displayed.



Use the **UP** or **DOWN** button to scroll backwards and forwards through the Calls list.

If the 'name' of your caller has been stored in the phonebook, this will be displayed. Press the  button and the number will be displayed.




Press the  button and the time of the call will be displayed.



Press the  button to go back to the Calls list.

Note

Press and hold the  button to return to the standby screen.

To dial a number from the Calls list



Press the **DOWN** button to enter the Calls list.



Use the **UP** or **DOWN** button to scroll to the number you want to dial.



Press the **TALK** button. The number will be dialled automatically.

To store a number from the Calls list into the Phonebook



Press the **DOWN** button to enter the Calls list.



Use the **UP** or **DOWN** button to scroll to the number you want to store in the phonebook.




Press the  button.

The display shows the date and time of the call.



Press the  button again, the display shows **ADD**.




Press the  button, the display shows **NAME ?**.



Press keypad buttons to enter name as described before under the "Entering names" section.

Note

You can enter names up to 8 characters long. If necessary, you can edit the entry, when the entry is correct, press the  button. The number is now stored in the phonebook.



Press the  button.

The name and number are now stored in the phonebook.

Important

Once stored in the phonebook the number will be deleted from the Calls list.

To delete a number from the Calls list



Press the **DOWN** button to enter the Calls list.



Use the **UP** or **DOWN** button to scroll to the number you want to delete.



Press the **✓** button *twice*, **ADD** will be displayed.



Use the **UP** or **DOWN** button to scroll to **DELETE ?** and press the **✓** button.



The number is deleted from the Calls list.

To delete all numbers from the Calls list



Press the **DOWN** button to enter the Calls list.



Press the **X** button. The display will show **DEL ALL**.



Press the **✓** button. The display will show **EMPTY** for 2 seconds.

*Call Waiting

If an incoming call arrives while you are already engaged on a telephone call, you will hear a soft beep every 5 seconds (this beep is not audible to the person you are speaking to). The second caller's number (and name if stored in the directory) will appear on the handset display.

Instead of the engaged tone, the second caller will hear an announcement to hold on as you are aware that there is a second call.

*You must subscribe to your network provider's Call Waiting Service before this feature will work. A quarterly fee is payable.

To accept a Call Waiting call

If you hear the tone that tells you there is another caller, whilst you are on a call:



Press the **Recall** button. The first caller will be put on hold and you can now speak to your second caller.



To return to the first caller press the **Recall** button again.

Note

You can switch back and forth between the two calls without disconnecting either if you wish.



If you wish to disconnect the first call press the **TALK** button after speaking to the first caller.




The handset will then ring. Press the **TALK** button again and continue with the second caller.

Note

The second caller will only be charged for their call from the moment you answer and not while they are waiting for your initial contact.

Using Synergy 3000 additional handsets and bases

Up to 5 handsets can be registered and operated from any one Synergy 3100 base. This allows you to make internal calls between two handsets while a third is making an external call.



Each handset can be registered on up to 4 bases.


Each additional handset you purchase must be registered with the base.

Your handset supplied is pre-registered as Handset 1 to its base (**Base 1**).

If you have purchased a Twin the additional handset supplied is pre-registered as Handset 2 (Base 1).

Note

Remember to charge the battery pack of new handsets for at least 16 hours before use.

If the display shows NOT SUB and the  symbol is flashing, your handset is not yet registered with the base.

To register a Synergy 3000 handset to another base

At the base:

Page


Press and hold the base **PAGE** button for at least 10 seconds, until you hear the validation tone (two beeps), then release the button.

At the handset:

Menu
✓

Press the  button to enter the menu.

Redial
▲
Vol
▼
Calls


Use the **DOWN** button to scroll to **REGISTER** and press the  button.


Menu
✓

The display will show
BS 1 2 3 4. (The numbers

that are flashing indicate other bases that the handset is already registered to).

Enter the base number (**BS 1-4**) that you want to register the handset to.

Enter your 4-digit PIN (original factory setting 0000) and press the  button.

The display will show SEARCH 1, 2, 3, 4 and the  symbol will flash as the handset tries to locate the base. When the handset locates the base, the handset will be automatically selected and shown on the display.

Note

If the handset does not locate the base, the handset will return to the previous menu. Try to register again by using a different available base number. Ensure that you are in close vicinity of the base).

Note

Your 4 digit PIN number is 0000 unless you have previously allocated a new PIN number as explained on page 23.

To de-register a Synergy 3000 additional handset from the base


Note

Handsets can only be de-registered via another handset.




Press the  button to enter the menu.



Use the **DOWN** button to scroll to **SETUP** and press the  button.



Use the **DOWN** button to scroll to **DEL HS** and press the  button.



The display will show **PIN?**

Enter your 4-digit PIN.



Press the  button.




Use the **UP** or **DOWN** button to select the handset you want to de-register (**HANDSET 1-5**).



Press the  button. Display shows **CONFIRM?**



Press . You will hear a confirmation beep.

Once de-registered, the handset will display **NOT SUB.**

Internal calls

If you have multiple handsets registered to the base you can make internal calls between handsets.

To make an internal call to another handset



Press the **INT** button.



Enter the number of the handset you wish to call, **(1-5)**.
The called handset will ring

The display will show **INT**.



To end the call, press the **TALK** button.

Transferring calls

You can transfer an external call to another handset registered to the base.

To transfer an external call between handsets

During an external call:



Press the **INT** button.



Enter the number of the handset that you want to transfer the call to **(1-5)**.

Your caller will be put on hold.

When the internal handset is answered, (if you want to you can talk to the handset user first), press the **TALK** button. The call will be transferred.

If the call to the second handset is not answered you can revert/speak to the caller again by pressing the **INT** button.



Three-way conversation

You can talk to one external caller and another internal caller at the same time on your handset.

During a call with an external caller:



Press the **INT** button. Your caller is put on hold and you hear a tone.



Enter the number of the handset you want to transfer the call to.



When the handset is answered, press and hold the **#** button for about 3 seconds. You can now start your three-way conversation. (If the internal handset user does not answer your call, press the **INT** button to return to your external caller).



Press the **TALK** button to end the call.



Note

When on a three-way call the call can only be cleared by the handset which set it up.

Press the button to exit the call.

Handset Priority



Press the button to enter the menu.



Use the **DOWN** button to scroll to **SETUP** and press the button.



Use the **DOWN** button to scroll to **PRIORITY** and press the button.



Use the **DOWN** button to scroll to **SELECT**.



Press the button.



Use the **DOWN** button to display the option you want, either **BASE** or the handset number you require, eg **HANDSET 3**.



Press the button. The display shows **RINGS** followed by a number between 1 and 9.



Use the **DOWN** button to scroll to the number of rings you require.



Press the button. **PRIORITY** is displayed, denoting that handset priority is on.



Press the button to confirm. The display shows **ON**.

Help


Replacing the handset batteries.

After a time, you may find that the handset batteries are running out of charge more quickly. This is a standard sign of wear and the batteries will need replacing.

For spare 2 x AAA rechargeable batteries please contact the Synergy 3100 Helpline **08706 058 047**.

Replacing the batteries

In the event that you should need to change or replace the batteries: Remove the battery compartment cover and take out the batteries. Insert new 2 x AAA re-chargeable batteries and replace the battery compartment cover.



Do not immerse the batteries in water or throw into a fire, or dispose of with ordinary domestic refuse.

BT accepts no responsibility for damage caused to your Synergy handset by using any other type of batteries.

No display appears.

The batteries may be flat or dead. Recharge or replace the batteries.

The handset may be switched off.

No dial tone.

Is the telephone line cord plugged into the phone socket?

Check that: The base station is connected to the mains power and switched on.

You cannot link up with the base station.

Is the display flashing  ?

The mains power cable may not be connected at the base or switched on.

Are you in range of the base station?

The batteries could be low or flat.

If using more than one base station, check that you are connected to the correct base. *See page 23.*

Handset does not ring.

The ringer volume may be switched to off. To adjust the ringer volume on the handset. *See page 19.*

Check that: The base station is plugged into the phone socket.

Check that: The base station is plugged into the mains power and switched on.

Buzzing noise on my radio, TV, computer or hearing aid.

Sometimes, your Synergy 3100 can interfere with other electrical equipment if it is placed too close.

It is recommended that you place your Synergy 3100 and other Synergy/ DECT GAP compatible handsets at least one metre away from such appliances to avoid any risk of interference.

The charger does not appear to be working.

Check that: The power adaptor is properly plugged into the charger.

Check that: Your handset has slotted correctly into the charger.

Check that: The batteries are correctly fitted into the handset.


Check that: The base is plugged in to a working socket and that the socket is switched on.

Are you using the correct power adaptor?

Synergy 3100 base station power supply is Item Code 872260.

Cannot adjust an option in the base station.

Is someone else making changes via another handset?

Have you pressed the  button to confirm your selection?

Customer Helpline

If you are still experiencing difficulty, call the Synergy 3100 Helpline on 08706 058 047.

General information

Guarantee

Your Synergy 3100 is guaranteed for a period of 12 months from the date of purchase.

Subject to the terms listed below the guarantee will provide for the repair of, or at BT's or its agent's discretion, the option to replace the Synergy 3100, or any component thereof, (other than the batteries), which is identified as faulty or below standard, or as a result of inferior workmanship or materials. Products over 28 days old from the date of purchase may be replaced with a refurbished product.

The conditions of this guarantee are:

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is provided.
- The equipment is returned to BT or its agent as instructed.
- This guarantee does not cover the battery pack and any faults or defects caused by accidents, misuse, fair wear and tear, neglect, storm damage, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.
- This guarantee does not affect your statutory rights.

Within the 12 month guarantee period:

If you experience difficulty using the product, prior to returning your product, please read the Help section beginning on *page 33*, or contact the Synergy 3100 Helpline for assistance:

Helpline **08706 058 047**, 9am to 5.30pm Monday to Friday.

In the unlikely event of a defect occurring, please follow the Helpline's instructions for replacement or repair.

Outside of the 12 month guarantee period:

If your product needs repair after the guarantee period has ended, the repair must meet the approval requirements for connection to the telephone network. We recommend that you contact BT's approved repair agent, TecLogic on 01672 564444 or a local qualified repairer.

Instructions for returning the product:

If the Helpline is unable to remedy your problem they will ask you to return the product. Where possible, pack the product in its original packaging. Please remember to include all parts, including line cords, power supply units, and the original

batteries. (Please note that we cannot take responsibility for goods damaged in transit.) Please obtain and keep proof of posting from the Post Office.

Technical information

How many telephones can you have?

All items of telephone equipment have a Ringer Equivalence Number (REN), which is used to calculate the number of items which may be connected to any one telephone line. Your Synergy 3100 has a REN of 1. A total REN of 4 is allowed, if the total REN of 4 is exceeded, the telephones may not ring.

With different telephone types there is no guarantee of ringing, even when the REN is less than 4.

Only use approved power supply, item code 872260.

Use only approved (Ni-MH) rechargeable batteries.

Switchboard compatibility

This product is intended for use within the UK for connection to the public telephone network and compatible switchboards, which support tone dialling and timed break recall. If in doubt please consult your service provider.

Switchboard external line access code

You may need to enter an access code (e.g. **9**) in order to get an outside line. So that the switchboard has time to pick up an outside line, you may also need to add a Pause after the access code.

Recall

To use the recall button




This is used when connected to certain switchboards and for some BT Select Services or those services available via your network provider.

To set the dialling mode




Press the  button to enter the menu.



Use the **DOWN** button to scroll to **SETUP** and press the  button.



Use the **DOWN** button to scroll to **DIALMODE** and press the  button.



Use the **UP** or **DOWN** button to select either **TONE** or **PULSE**.



Press the  button. You will hear a confirmation beep.

To automatically insert a pause after an access code

With some switchboards it may be helpful to dial a pause after entering the switchboard access code, e.g. 9, 11 etc. to enable you to get an outside line.

This feature automatically inserts a pause between the access code and the telephone number that you have entered in the Phonebook. However for this feature to work you must still enter the access code at the front of the telephone number when storing in the Phonebook.



Press the  button to enter the menu.



Use the **DOWN** button to scroll to **SETUP**.



Press the  button.



Use the **DOWN** button to scroll to **PAEX**.




Press the  button.



Use the **DOWN** button to scroll to **PEX 1**.



Press the  button.
Display shows **PIN?**.
Enter PIN number.



Press the  button.

Enter the access code.



Press the  button.

You can also adjust the length of the pause to be inserted. There are two options available, 3 or 5 seconds to be set to suit the switchboard:



Press the  button.



Use the **DOWN** button to scroll to **SETUP**.



Press the  button.



Use the **DOWN** button to scroll to **PAEX**.



Press the  button.



Use the **DOWN** button to scroll to **PAUSE**.

Display shows **3 SEC**.



Use the **DOWN** button to scroll to **5 SEC**.



Press the  button. You will hear a confirmation tone.

Index

Additional handsets	29	delete all	27
Auto talk on/off	20	dial number	26
Base ringer volume	22	enter	26
Base settings		store in phonebook	26
default/reset	24	view	26
diagram	2	Call timer	13
melody	22	Call Waiting	27
PIN number	23	Cleaning	9
ringer volume	22	Delete	
select which base station	23	calls list	27
Batteries		phonebook numbers	18
charging	11	De-register	30
install	11	Dialling mode	36
low warning	11	Display icons	2
performance	12	E arpiece volume	14
replacing	33	End a call	14
Button beeps on/off	19	G uarantee	35
Caller Display	25	H andset settings	
Calls		default/reset	24
end	14	keypad beeps on/off	19
handsfree	14	language setting	21
internal	31	name handset	21
make	13	on/off	13
preparatory dialling	13	register to another base	29
receive	14	ringer melody	20
redial	15	ringer priority	32
secrecy	15	ringer volume	19
three-way conversation	32	Handsfree	14
transfer	31		
Calls list	25		
delete	27		

Help	33	Redial	15
Helpline	12	Register handset to another base	29
Internal calls	31	REN (Ringer Equivalence Number)	36
Keypad beeps on/off	19	Reset handset/base	24
Language	21	Returning your Synergy 3100	35
Location of product	10	Ring priority	32
Make a call	13	Ringer melody	
Melody		base	22
base	22	handset	20
handset	20	Ringer volume	
Menu structure	4	base	22
Name a handset	21	handset	19
On/off		Safety information	9
auto-talk	20	Secrecy	15
handset	13	Setting up	10
keypad beeps	19	Speech volume	14
secrecy	15	Storing a number	16
Pause – insert	17, 37	Switchboard access code	36
Paging handsets	18	Switchboard compatibility	36
Phonebook	16	Technical information	36
delete	18	Telephone line cord	12
dial	17	Three-way conversation	32
edit	17	Transfer calls	31
enter a pause	17	Unpacking	8
store	16	Volume	
PIN base	23	base ringer	22
Power supply	10	earpiece	14
Preparatory dialling	13	handset ringer	19
Quick guide – handset settings	3	handsfree	15
Recall	36		
Receive a call	14		

Accessories and spares


For the Synergy 3100 range of telephones

Accessories and spares for the Synergy 3100 range of telephones are listed below.


All items are available from the Synergy Helpline, please call
08706 058 047

Additional handsets and chargers:

In Titanium:
Item code 005717




Additional chargers:



Power supply units for the base unit or charger

Plug mounted,
13 amp mains adaptor.
Item code 872260



Telephone line cord



Batteries



Battery cover



User guide



R&TTE

This product is intended for use within the UK for connection to the public telephone network and compatible switchboards.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive 1999/5/EC.

Declaration of Conformance.

Hereby, Suncorp Technologies, declares that this Synergy 3100 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The Declaration of Conformance for the Synergy 3100 is published on the web site

<http://www.suncorpotech.com/bt>



Offices worldwide

The telecommunications services described in this publication are subject to availability and may be modified from time to time. Services and equipment are provided subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of any contract.

Touchtone™ is a registered trade mark of British Telecommunications plc in the UK.

© British Telecommunications plc 2002.
Registered Office: 81 Newgate Street, London EC1A 7AJ.
Registered in England No. 1800000.
Designed by: The Art & Design Partnership Limited.
Printed in China. Synergy 3100. Issue 1 (7/02) 3

